

DIRT:

1. Allow stain to dry fully before attempting to remove.
2. Follow treatment for non-oil stains.

NON-OIL STAINS:

1. Start with a suede cleaning brush as a simple spot treatment for the stain. Brush in one direction to start, and then in a circular motion for tougher stains.
2. If the stain remains, gently rub the stain out with the rubber eraser.
3. If the stain is still visible, spray with suede cleaning spray, let dry, then brush again.

OIL/GREASE STAINS:

1. Apply corn starch immediately to the wet stain and let sit overnight.
2. Remove corn starch and gently rub with brush to remove excess.

MATERIAL GRADE TESTED WAS DESIGNED TO MEET HIGH PERFORMANCE FOOTWEAR SPECS

*RESULTS MAY VARY BASED ON COLOR

**INTENDED FOR SUEDE LIKE MATERIALS ONLY

ALL PRODUCT, PRODUCT SPECIFICATIONS AND DATA ARE SUBJECT TO CHANGE WITHOUT NOTICE TO IMPROVE RELIABILITY, FUNCTION OR DESIGN OR OTHERWISE. Modern Meadow, Inc. disclaims any and all liability for any errors, inaccuracies or incompleteness in this datasheet.



CONTACT US AT: WWW.MODERNMEADOW.COM
SALES@MODERNMEADOW.COM